



Installation Instructions For 2019+ BMW 320i 330i (G20)

KIT CONTENTS

NO.	DESCRIPTION	QTY
1	Intake Pipe	1
2	Heat Shield	1
3	Heat Shield Cover	1
4	M4 Bolt 8mm	6
5	M4 Spring Washer	4
6	M4 Washer	4
7	M6 Bolt	1
8	M6 Nut	1
9	M6 Washer	2
10	M8 Bolt	1
11	M8 Nut	1
12	M8 Washer	2
13	Silicone turbo inlet pipe	1
14	Clamps	2
15	Air Filter 89/115mm	1

Please Check the Contacts of this box immediately.

Report any defective or missing parts to us or our dealer that you purchased this product form.

Before installing any parts of this system, please read the instructions thoroughly. If you have any questions regarding installation please contact the our dealer or local modified car factory.

Installing does require some mechanical skills. A qualified mechanic is always recommended.

※Do not attempt to install the intake system while the engine is hot.

The installation may require removal of radiator fluid line that may be hot.

MST Performance Auto Parts offers a limited lifetime warranty to the original purchaser against defects in materials and workmanship. Warranty claims must be handled through the dealer from which the item was purchased.

*All installation of parts must be performed by a trained professional.





Figure 1: Loosen the hose clamp.




Figure 4: Remove the PCV.



Figure 2: Disconnect the mass air sensor.




Figure 5: Remove the stock turbo inlet pipe spring.



Figure 3: Remove the stock air box.




Figure 6: Remove the PCV.



Figure 7: Remove the stock turbo inlet pipe.



Figure 10: Install the O-Ring.



Figure 8: Remove the PCV.



Figure 11: Install the spring.



Figure 9: Remove the O-Ring.



Figure 12: Install the silicone turbo inlet pipe.



Figure 13: Install the PCV.




Figure 16: Secure the heat shield bracket with bolt.




Figure 14: Install the heat shield.



Figure 17: Remove the mass air flow sensor from the stock air box.



Figure 15: Secure the heat shield bracket with bolt.



Figure 18: Install mass air sensor into the intake pipe.




Figure 19: Install the intake pipe.



Figure 22: Install the heat shield cover and secure with bolt




Figure 20: Plug in the mass air flow sensor connector.



Figure 23: Congratulations! You have just completed the installation of this intake system. Periodically, check the alignment of the intake, normal wear and tear can cause nuts and bolts to come loose.



Figure 21: Install the air filter.